CHRISTEYNS



MIDA ENZY 1002

Mida

Foaming enzymatic product for biofilm removal at room temperature

DESCRIPTION AND APPLICATION

MIDA ENZY 1002 is a foaming enzymatic detergent formulated for the control and elimination of biofilms of surfaces in the food industry at room temperature ($\geq 20^{\circ}$ C). It it is recommended for both preventive and shock anti-biofilm treatments. **MIDA ENZY 1002** contains a blend of enzymes combined with surfactants with a strong cleaning capacity towards removing fat and protein residues.

INSTRUCTIONS OF USE

MIDA ENZY 1002 it is applied by means of a foam projection equipment at a 1.5-3% concentration for anti-biofilm preventive treatments or at 3-5% for anti-biofilm shock treatments with water at room temperature (≥20°C optimum) during 15 - 30 minutes. Rinse thoroughly with water.

MIDA ENZY 1002 should always be followed by a disinfection phase preferably using an oxidising disinfectant. Rinse thoroughly with water at the end to eliminate any possible residues from all surfaces in contact with food and drink.

Recommendations:

- For preventive treatments: determine periodicity according to type of industry.
- For shock treatment: Repeat the treatment daily 3 to 5 consecutive days.
- Before an enzymatic shock treatment, it is recommended to perform an alkaline cleaning. Verify that there are no alkaline residues prior to treatment that could inactivate the enzymatic function.

PRODUCT CHARACTERISTICS Main ingredients Anionic surfactants, non-ionic surfactants and enzymes. Visual aspect Clear liquid Colour Light yellow Odour Characteristic of the product pH (100%) ± 8.0 Relative density (at 20°C) ± 1.06

The values provided in the table do not constitute technical specifications

CHRISTEYNS

MATERIALS COMPATIBILITY

MIDA ENZY 1002 when applied at the recommended concentrations and temperatures, is compatible with all types of materials commonly used in the food industry including aluminium and soft alloys. If uncertain, it is recommended to assess each individual material component individually before extended contact

ENVIRONMENT

MIDA ENZY 1002 does not contain any chlorine and hence there is no risk of the formation of organic absorbable halogens (AOX).

MIDA ENZY 1002 complies with the European Union directive EU648/2004 on biodegradability of surfactants.

SAFETY

MIDA ENZY 1002 is classified as corrosive.

Hazard classification (CLP): H318 - Causes serious eye damage.

H412 – Harmful to aquatic life with long lasting effects.

Do not mix with strong acids, strong bases, or any other product.

Please consult the MSDS and follow the guidance for handling and disposal.

STABILITY AND STORAGE

Store the product sealed in its original packaging between 5 and 25°C and prevent any leakage of product. Do not expose to direct sunlight. More detailed recommendations are available in the Safety section 7

Shelf life: Use before the expiring date indicated on the packaging (18 month after production date).

PACKAGING

20 L

Technical Data Sheet Mida Enzy 1002 Revision: March 2022

CHRISTEYNS NV Afrikalaan 182, B – 9000 Gent (Belgium) Tel +32 9 223 38 71 · Fax +32.9 233 03 44 · www.christeyns.com