CHRISTEYNS



MIDA FOAM 165 UD

Powerful alkaline foam detergent for ovens, smoking chambers and smoke houses

DESCRIPTION & APPLICATION

MIDA FOAM 165 UD is a liquid alkaline detergent for use in food processing areas, especially for the cleaning of smoking chambers, also in the presence of hard water.

MIDA FOAM 165 UD is ideal for removing carbonized deposits and soils in ovens, smoking chambers and fryers.

MIDA FOAM 165 UD is is a strong alkaline detergent combining surfactancy and calcium & magnesium sequestration in a highly effective cleaning action.

MIDA FOAM 165 UD is powerful in removing fatty deposits from conveyor hooks in slaughterhouses.

MIDA FOAM 165 UD is a strong alkaline detergent combining surfactancy and solvent action in a highly effective cleaning action.

USE INSTRUCTIONS

MIDA FOAM 165 UD is used at concentrations between 1-5% (v/v) at a temperature of 30-60°C depending on the degree and type of soiling to be removed and the water hardness. After a contact time of at least 10 to 30 min rinse thoroughly after use (within 1 hour) and ensure that all product residues and soil particles are removed.

PRODUCT CHARACTERISTICS

Composition	Contains caustic soda, surfactants, sequestrants.
Appearance	Clear liquid
Colour	Dark brown
Odour	Characteristic of the product
pH (1%)	± 12,9
Density	± 1,30 g/cm ³ (20°C)
Solubility	Miscible in water in all proportions

CHRISTEYNS s.r.o. • Vítovská 453/7 • 742 35 Odry • Czech Republic Tel/Fax: +420 556 731 111 • www.christeyns.com

CHRISTEYNS

MATERIAL COMPACTIBILITY

When **MIDA FOAM 165 UD** is used according to the recommended use instructions, then **MIDA FOAM 165 UD** can be used on materials commonly used in the food industry, with the exception of light alloys, galvanized material and soft metals like aluminium.

ENVIRONMENT

MIDA FOAM 165 UD does not contain any chlorine and hence there is no risk of the formation of organic adsorbable halogens (AOX).

The surfactants of **MIDA FOAM 165 UD** comply with the European Union Directive EU648/2004 on the biodegradability of surfactants.

SAFETY

Never mix **MIDA FOAM 165 UD** with other products. Carefully read the material safety data sheet of **MIDA FOAM 165 UD** and follow the chemical handling and disposal guidance.

STORAGE

Store **MIDA FOAM 169 FR** in its original packaging between 5°C and 30°C. Do not expose to direct sunlight. The expiry date is 24 months from date of manufacture.

PACKAGING

MIDA FOAM 165 UD can be available in CAN, DRUM and IBC.

Technical Data Sheet MIDA FOAM 165 UD Revision 28.02.2018

> CHRISTEYNS s.r.o. • Vítovská 453/7 • 742 35 Odry • Czech Republic Tel/Fax: +420 556 731 111 • www.christeyns.com