

# **MIDA IDEAL**

Neutral foam detergent for manual cleaning for the food industry and institutional hygiene

## **DESCRIPTION & APPLICATION**

**MIDA IDEAL** is a neutral liquid foam detergent especially developed for the manual cleaning of tools and small equipment (for example) cutting equipment, slicing, wrapping and filling machines and other equipment, machines, tools and instruments) in food processing areas.

**MIDA IDEAL** is a product based on neutral pH with a high level of anionic surfactants, but which rinses easily without leaving marks on the cleaned surfaces.

**MIDA IDEAL** can be used also in hard water conditions – treated surfaces are after use bright and shiny.

## **USE INSTRUCTIONS**

**MIDA IDEAL** is used at concentrations between 0,1-1,0% (v/v) at a temperature of  $30-40^{\circ}$ C depending on the degree and type of soiling to be removed and the water hardness. Rinse thoroughly after use and ensure that all product residues and soil particles are removed.

## PRODUCT CHARACTERISTICS

Composition	Contains anionic surfactants, sequestrants, stabilizer, preservative.
Appearance	Clear (moderately viscous) liquid
Colour	Yellow
Odour	Characteristic of the product
pH (1%)	± 7,0
Density	± 1,00 g/cm <sup>3</sup> (20°C)
Solubility	Miscible in water in all proportions

## **MATERIAL COMPACTIBILITY**

When **MIDA IDEAL** is used according to the recommended use instructions, then **MIDA IDEAL** can be used on materials commonly used in the food industry.



## ENVIRONMENT

**MIDA IDEAL** does not contain any chlorine and hence there is no risk of the formation of organic adsorbable halogens (AOX).

The surfactants of **MIDA IDEAL** comply with the European Union Directive EU648/2004 on the biodegradability of surfactants.

## **SAFETY**

Never mix **MIDA IDEAL** with other products. Carefully read the material safety data sheet of **MIDA IDEAL** and follow the chemical handling and disposal guidance.

## STORAGE

Store **MIDA IDEAL** in its original packaging between 5°C and 30°C. Do not expose to direct sunlight. The expiry date is 24 months from date of manufacture.

## **PACKAGING**

MIDA IDEAL can be available in CANS and DRUM.

Technical Data Sheet **MIDA IDEAL** Revision 28.02.2018